

Advanced App Traffic Capture

Monday, December 24, 2018 2:31 PM

Traceroute

Windows	tracert
*nix	traceroute

Max

Windows	-h NUM
*nix	-m NUM

Routing tables:

Windows	route print
*nix	netstat -r

Enabling Routing: 0 to disable

Windows	reg add HKLM\System\CurrentControlSet\Services\Tcpip\Parameters ^ /v IPEnableRouter /t REG_DWORD /d 1
*nix	sysctl net.ipv4.conf.all.forwarding=1 sysctl net.ipv6.conf.all.forwarding=1
MacOS	sysctl -w net.inet.ip.forwarding=1

NAT: 2 types common today:

1. SNAT: Source Network Address Translation
2. DNAT: Destination Network Address Translation
 - Diff bet 2: Which address is modified during NAT processing of traffic

Enabling SNAT:

- When you want rtr to hide multiple machines behind single IP
- Source IP addr in packets rewritten to match addr made by SNAT

Config SNAT on Linux: Make sure to: Enable IP routing: Find name of outbound net int w/ifconfig [eth0]

Flush existing NAT rules	iptables -t nat -F
Outbound int has fixed addr	iptables -t nat -A POSTROUTING -o INTNAME -j SNAT --to INTIP
IP addr config dynamically	iptables -t nat -A POSTROUTING -o INTNAME -j MASQUERADE

Enabling DNAT: Useful if redirecting traffic to proxy/service to terminate before fwding traffic

- Rewrites dest IP/port

Flush existing NAT rules

run as root `iptables -t nat -A PREROUTING -d ORIGIP -j DNAT --to-destination NEWIP`

Apply rule only to specific TCP/UDP change:

`iptables -t nat -A PREROUTING -p PROTO -d ORIGIP --dport ORIGPORT -j DNAT \ --to-destination NEWIP:NEWPORT`

DHCP spoofing: Ettercap: GUI mode: `ettercap -G`

Sniff > Unified Sniffing | Mitm > DHCP spoofing | Start > Start sniffing

ARP Poisoning: Ettercap > Unified Sniffing > Hosts > Scan for Hosts > Hosts Host List

- Add to Target 1: Select host to poison > Add to Target 2
- Mitm > ARP poisoning > OK

Utilizing WS: Statistics > Conversations after capture > Follow Stream [TCP]

ID Packet Structure w/Hex Dump:

- WS has a Hex Dump option when Following TCP Streams from drop down menu



- 1: Byte offset into the stream for a direction:
 - Byte at 0: 1st byte sent in that direction
 - Byte 4: is the 5th
- 2: Shows bytes as hex dump
- 3. ASCII representation

Viewing Individual Packets:

- Each block is a single TCP packet/segment: Only about 4 bytes of data

TCP: Stream-based protocol:

- No real boundaries bet consecutive blocks of data when reading/writing to sockets
- Sends individual packets consisting of TCP header containing info
- **Edit > Find Packet**

Determining Protocol Structure: Look only at 1 direction of network comm

Binary Conversion w/Python Script:

- Can use Python built-in struct lib to do binary conversions
- Should fail if something isn't right: Ex. Not being able to read all data expected from file

```

1 from struct import unpack
2 import sys
3 import os
4
5 # Read fixed number of bytes
6 def read_bytes(f,1):
7     bytes = f.read(1)
8     if len(bytes) != 1:
9         raise Exception("Not enough bytes in stream")
10    return bytes
11
12 # Unpack 4-byte network byte order int
13 def read_int(f):
14     return unpack("!i", read_bytes(f,4))[0]
15
16 # Read single byte
17 def read_bte(f):
18     return ord(read_bytes(f,1))
19
20 filename = sys.argv[1]
21 file_size = os.path.getsize(filename)
22
23 f = open(filename, "rb")
24 print("Magic: %s" % read_bytes(f,4))
25
26 # Keep reading until EOF
27 while f.tell() < file_size:
28     length = read_int(f)
29     unk1 = read_int(f)
30     unk2 = read_byte(f)
31     data = read_bytes(f, length -1)
32     print("Len: %d, Unk1: %d, Unk2: %d, Data: %s"
33           % (length, unk1, unk2, data))

```

1. **read_bytes()**: Reads fixed # of bytes from file specified as param
 - If not enough in file: Exception thrown
2. **read_int()**: Reads 4-byte int from file in network byte order
 - Most significant byte of int is 1st in file/defines a func to read single byte
3. Opens file passed on cli/1st 4-byte value
4. **Loop**: Data to read: Length, 2 unknown values, data, prints values to console

python3 read_protocol.py bytes_inbound.bin

Calculating the Checksum

- If we assume that the unknown value is a simple checksum
- Can sum all bytes in the ex. outbound/inbound packets

2 easy ways to determine whether guessed correctly:

1. Send simple incrementing msgs from a client (A/B/C/etc): Capture/analyze
 - **If checksum simple addition:** Value should increment by 1 for each msg
2. Add function to calc checksum to see whether it matches bet capture on network/value

```
35 # Checksum function
36 def calc_chksum(unk2, data):
37     chksum = unk2
38     for i in range(len(data)):
39         chksum += ord(data[i:i_1])
40     return chksum
```

Dev WS Dissectors in Lua:

- Easy to analyze a protocol like HTTP w/WS bc SW can extract all necessary info
- Custom protocols more challenging:
 - Manually extract all relevant info from byte representation of network traffic
 - Can use WS plug-in Protocol Dissectors to add addl analysis
 - Modern versions support Lua scripting
 - Will also work w/tshark cli tool

Load Lua files: Put scripts in %APPDATA%\Wireshark\plugins dir

Linux/macOS: ~/.config/wireshark/plugins dir

- Can also load Lua script by specifying on cli: **wireshark -X lua_script:</path.lua>**

Creating the Dissector:

```
1 -- Declare chat protocol for dissection
2 chat_proto = Proto("chat", "SuperFunkyChat Protocol")
3
4 -- Specify protocol fields
5 chat_proto.fields.chksum = ProtoField.uint32("chat.chksum", "Checksum",
6     base.HEX)
7 chat_proto.fields.command = ProtoField.uint8("chat.command", "Command")
8 chat_proto.fields.data = ProtoField.bytes("chat.data", "Data")
9
10 -- Dissector function
11 -- buffer: UDP packet data as a "Testy Virtual Buffer"
12 -- pinfo: Packet info
13 -- tree: Root of the UI tree
14 function chat_proto.dissector(buffer, pinfo, tree)
15     -- Set name in the protocol column in the UI
16     pinfo.cols.protocol = "CHAT"
17
18     -- Create sub tree which represents entire buffer
19     local subtree = tree:add(chat_proto, buffer(),
20         "SuperFunkyChat Protocol Data")
21     subtree:add(chat_proto.fields.chksum, buffer(0,4))
22     subtree:add(chat_proto.fields.command, buffer(4,1))
23     subtree:add(chat_proto.fields.data, buffer(5))
24 end
25
26 -- Get UDP dissector table/add for port 12345
27 udp_table = DissectorTable.get("udp.port")
28 udp_table:add(12345, chat_proto)
```

1. Creates new instance of Proto class: Represents instance of a WS protocol/assigns name **chat_proto**
 - Although you can build dissected tree manually: Chosen to define specific fields for protocol
2. Fields will be added to display filter engine: You'll be able to set display filter of **chat.command == 0**
 - WS won't only show packets w/cmd 0
 - Useful for analysis: You can filter down to specific packets easily/analyze separately

3. Script creates dissector() function on instance of Proto class: Will be called to dissect packet
 - **Function has 3 params:**
 - Buffer containing packet data is an instance of something WS calls TVB: Testy Virtual Buffer
 - Packet info instance represents display info for dissection
 - Root tree object for UI: Can attach subnodes to tree to generate display of packet data
4. **Set the name of protocol in UI column**
5. **Build a tree of protocol elements dissecting**
 - UDP doesn't have explicit field length: Don't need to bother
 - Only need to extract checksum field
 - Add to subtree using protocol fields
 - Use the buffer param to create a range: Takes a start index into buffer/optional length
 - No length? Rest of buffer used
 - Register protocol dissector w/WS's UDP dissector table
6. Get UDP table/add **chat_proto** object to table w/port 12345